

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5

CONTROL TABLE OF TRANSMISSION POINTER VALUES AT END OF FRAMES																
Fr #	#71	#72	#73	#74	#75	#76	#77	#78	#79	#80	#81	#82	#83	#84	#85	#86 #87 #88
0	100	101	105	106	106	106	108	108	108	110	113	113	113	117	119	120 120
1		100	101	105	106	106	106	108	108	108	110	113	113	113	117	119 120
2		100	101	105	106	106	106	106	108	108	110	113	113	113	117	119 119
3			100	101	105	106	106	106	106	108	108	110	113	113	113	117 119
4				100	101	105	106	106	106	106	108	108	110	113	113	113 117
5					100	101	105	106	106	106	106	108	108	110	113	113 113
6						100	101	105	106	106	106	106	108	108	110	113 113
7							100	101	105	106	106	106	108	108	110	113 113
8								100	101	105	106	106	106	108	108	110 110
9									100	101	105	106	106	106	108	108 108
10										100	101	105	106	106	106	108 108
11											100	101	105	106	106	108 108
12												100	101	105	106	106 106
13													100	101	105	106 106
14														100	101	105 106
15															100	101 105
16																100 101

51 { 52 { 53 { 54 { 55 { 56 { 57 { 58 59

FIG. 6




FIG. 7




FIG. 8




FIG. 9




FIG. 10




FIG. 11




FIG. 12

